


# MYLEK<sup>®</sup>

Manual for use with model numbers:  
MYTH01D, MYTH02D, MYTH03D, MYTH04D

## Digital Tubular Heater



This item gets very hot: do not touch the tubular heater when it is switched on. Do not cover the tubular heater as this will cause overheating. Never place the tubular heater directly on the floor without using the feet.



**WARNING:** Check the product before use: if the cord is damaged, it must be replaced by the manufacturer if still under warranty, or similar qualified person to avoid any hazards.

READ ALL INSTRUCTIONS PRIOR TO USE.

[www.hsdonline.co.uk](http://www.hsdonline.co.uk)

# Introduction

## General Information

Please read the entire instruction manual before using the product and then save it for future reference. We reserve the right for any errors in text or images and any necessary changes made to technical data. If you have any questions concerning technical problems please contact our Customer Services on 0800 091 3171.

## Contents

2. Introduction
3. Safety Instructions
4. Installing and Operating
5. Operation
6. Cleaning
6. Specifications and Technical Data
7. Environmental Responsibilities
7. Warranty

## Safety Instructions

General safety instructions for the Digital Tubular Heater:  
Warning: Read all the instructions. Failure to comply with the following instructions can lead to electric shocks, fires or serious injury.



**SAVE THESE INSTRUCTIONS.**

The term “tubular heater” in the following text refers to your mains operated unit.

### 1. Safety Regulations

During the first use the heater may emit a small amount of vapour which is perfectly normal. The reason for this is the heating wire element is coated with lubricant oil during the production process. This will stop after approx. 5 minutes after the first use and is not a safety concern.

**IT IS IMPORTANT ALL ELECTRICAL DEVICES ARE PLUGGED INTO POWER THAT IS PROTECTED BY A SAFETY SWITCH.**

- The tubular heater is not suitable for use outdoors.
- Do not submerge into water.
- Place in a safe place away from flammable objects.
- Do not place flammable liquids or gasses near the heater.
- Do not place the heater directly below the socket outlet.
- Do not let the power cord over hang or touch the tube.
- Keep out of reach of children and animals – product gets hot to touch.
- **THE SURFACE OF THIS TUBULAR HEATER CAN STILL GET HOT. IT IS THEREFORE RECOMMENDED THAT THE AGED, INFIRM, CHILDREN AND ANIMALS ARE NOT LEFT UNSUPERVISED IN THE VICINITY OF THE HEATER UNLESS A SUITABLE GUARD IS FITTED.**
- This is not a toy.
- Switch off appliance when not in use.
- Do not hold or carry the tubular heater by the cord.
- If using an extension cord it must be as short as possible and fully extended.
- Check heater regularly if using with a timer or any other device that switches the tubular heater on or off automatically.
- This leaflet should be retained for instructions on use.

## 2 . Safety Thermal Cut-out


The appliance is fitted with a thermal cut-out. Once the tubular heater has cooled down it will re-set itself automatically.

## 3. Installing & Operating the Digital Controlled Tubular Heater

- THE TUBE HEATERS MUST BE MOUNTED HORIZONTALLY NOT VERTICALLY.

### Step 1.

- Install the support bracket to the tube heater as shown below using the fixings supplied.




### Step 2.

- Fix the tubular heater to your chosen position to the wall or floor.






### Important:

- The heater should have the following distances from walls or between 2 heaters.



## Step 3. Operation

DIGITAL TUBULAR HEATER: Advanced digital display, with smart working mode, touch button / screen display, thermal cut off, countdown timer and cyclically timer.

- A) Ensure the plug is plugged into the plug socket, the unit power light will illuminate showing the symbol "--" which means the unit is in standby mode and will not heat.
- B) Press the "on/off – setup" button and the unit will display "00" meaning the heater will operate heat continuously in normal mode with no timer settings.
- C) Press the "on/off – setup" button once more and  will display and "00" will flash; you can choose how many hours you want the unit to operate in a 1-24 hour period by pressing the up or down arrow. When the set hours have elapsed the unit will switch off.
- D) Press the "on/off – setup" button once again and  will display, and "00" will flash. This feature lets you set the time in hours for when you want the unit to switch on by pressing the up or down arrow, for example if you set to 4 hours the unit will count down and switch on after 4 hours have elapsed and will continuously give out heat until you switch the unit off.
- E) Press the "on/off – setup" button once again and  will display and "00" will flash. This feature lets you set the timer to come on and off cyclically, this means for example you choose 2 hours, the unit will operate for 2 hours and switch off for two hours and repeat this process until you switch the unit off. This feature is a great energy saving feature.
- F) The heater is fitted with a safety device which will switch off the heater in case of accidental overheating.
- G) To reset the tube heater, turn off the heater switch and unplug for a few minutes to allow the unit to cool down.
- H) Make sure that any causes of overheating, such as obstructions, are removed and plug the appliance in again and operate as normal.
- I) Turn off and unplug the unit when not in use or during the warmer months or when you are away from home for extended periods of time as a safety precaution and as a energy saving function.

## 4. Cleaning

- Ensure product is unplugged from the mains and left to completely cool down before attempting to clean.
- Wipe with a soft damp cloth and then dry with a soft dry cloth. **DO NOT** use abrasive cleaning powders, clothes or metal polishes on any part of the tubular heater as this will cause damage.

## 5. Digital Tubular Heater Specifications

Model No.	Power	Electrical Supply	IP Rating	Product Length (mm)
MYTH01D	60W	220-240V, 50 Hz	IP44	340mm
MYTH02D	120W	220-240V, 50 Hz	IP44	640mm
MYTH03D	180W	220-240V, 50 Hz	IP44	950mm
MYTH04D	240W	220-240V, 50 Hz	IP44	1250mm

## Environmental Responsibilities



Meaning of crossed-out wheeled dustbin:

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities.

Contact your local council for information regarding the collection systems available.

If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain damaging your health and well-being.



When replacing old appliances with new ones, the retailer is legally obligated to take back your old appliance for disposal free of charge.

## SERVICE WARRANTY

Hygiene Supplies Direct guarantees the product free from defects in materials and workmanship for a period of 1 year from date of purchase.

Should this unit be operated under conditions other than those recommended, at voltages other than the voltage indicated on the unit, or any attempts made to service or modify the unit, then the warranty will be rendered void. The product you buy may sometimes differ slightly from illustrations. This warranty is in addition to, and does not affect, your statutory rights.

If you have any problems with this product, please call our Help Desk on 0800 091 3171 or email [sales@hygienesuppliesdirect.com](mailto:sales@hygienesuppliesdirect.com)



YESSS Electrical Ltd, Normanton, WF6 1TN declares that the Tubular Heater is exclusively manufactured and imported for Hygiene Supplies Direct Ltd.

